EXCAVATOR HOOK - VABH-B



Complies with the machinery directives 2006/42/EC













NB: Please ensure that the safety instructions have been fully read and understood before initial use of the ABA weld-on lifting point. Failure to do so may result in serious injuries and/or material damage and eliminates manufacturers warranty.

User Instructions - Part 1

Safety instructions

This safety instruction/declaration of the manufacturer must be kept on file for the lifetime of the product.

ATTENTION: Please inspect all lifting points prior to use. Damage, incorrect assembly or improper use can result in serious injuries and/or material damage.

EC-Declaration of the manufacturer

According to the Machinery Directive 2006/42/EC, annex II B and amendments.

We hereby declare that the design and construction of the equipment detailed within this document, adheres to the appropriate level of health and safety of the corresponding EC regulation.

Any un-authorised modification and/or any incorrect use of the equipment not adhered to within these user instructions waivers this declaration invalid.

The equipment must be regularly tested and inspected as per BGR 500. Failure to carry out the recommended maintenance and testing waivers this declaration invalid.

Designation of the equipment:

Type: Excavator hook for bolting - VABH-B

Manufacturer's mark: ®

Drawings (iges, dxf and step), product information and other support material can be downloaded from www.rud.com.au.

		BRUD					
	EC-Declaration of	conformity					
According to	he EC-Machinery Directive 2006	6/42/EC, annex II A and amendments					
Manufacturer:	Manufacturer: RUD Ketten Rieger & Dietz GmbH u. Co. KG Friedensinsel 73432 Aalen						
as mentioned below, or health of the correspon mentioned harmonized	orresponds to the appropriate, building EC-Machinery Directive 20 and national norms as well as to	06/42/EC as well as to the below					
Product name:	Bolt on / Weld on hook	Bolt on / Weld on hook					
	VABH-B / VABH-W / VCGH-G	/ VCGH-S					
The following harmonia	ed norms were applied:						
	EN 12100 : 2011-03	EN 1677-1 : 2009-03					
The following national	norms and technical specifications						
	BGR 500, KAP2.8 : 2008-04	DIN 15428 : 1978-08					
Authorized person for t	he configuration of the declaration of Reinhard Smetz, RUD Kel						
Aalen, den 27.06.2014	DrIng. Arne Kriegsmann.	(Prokurist/QMB) fru friguna					

EXCAVATOR HOOK - VABH-B



User Instructions - Part 2

- **1.** Reference should be made to relevant standards and other statutory regulations. Inspections should be carried out by competent persons only.
- **2.** Before installing and every use, visually inspect RUD lifting points, with particular attention to any evidence of corrosion, wear and weld cracks and deformations. Please ensure compatibility of bolt thread and tapped hole.
- **3.** The material construction to which the lifting point will be attached, should be of adequate strength to withstand forces during lifting without deformation. RUD, with reference to the German testing authority BG, recommends the following minimum for bolt lengths:
- 1.5 x M in steel (minimum quality S235JR [1.0037]) ≈ AS3678 GR250.
- 1.5 x M in cast iron (for example GG 25)
- 2 x M in aluminium alloys
- 2.5 x M in aluminium-magnesium alloys
- (M = diameter of RUD lifting point bolt, e.g. M 20)

When lifting light metals, nonferrous heavy metals and gray cast iron, the thread has to be chosen in such a way that the working load limit of the thread corresponds to the requirements of the respective base material.

RUD excavator hooks are delivered with 100% crack tested bolts. When using your own bolts, the bolts have to be 100% crack tested. The min quality hexagon bolt has to be 10.9 accord. EN 24014 (DIN 931) with the nominal diameter.

- **4.** The lifting points must be positioned on the load in such a way that movement is avoided during lifting.
- a) For single leg lifts, the lifting point should be vertically above the centre of gravity of the load.
- b) For two leg lifts, the lifting points must be equidistant to/or above the centre of gravity of the load.
- c) For three and four leg lifts, the lifting points should be arranged symmetrically around the centre of gravity in the same plane if possible.

The installation should be in the direction of pull (picture 1).

5. Load Symmetry: The working load limit of individual RUD lifting points are calculated using the following formula and are based on symmetrical loading:

$$W_{LL} = \frac{G}{n \times \cos \beta}$$

$$W_{LL} = \frac{G}{n \times \cos \beta}$$

$$W_{LL} = \frac{1}{\text{equired of lifting point/individual leg (kg)}}$$

$$G = \frac{1}{\text{load weight (kg)}}$$

$$n = \frac{1}{\text{number of load bearing legs}}$$

$$\beta = \frac{1}{\text{equired of lifting point/individual leg (kg)}}$$

NOTE: For WLL Calculations

- ß angle is taken from the vertical plane.
- Included angle is the angle between the sling legs.
- **6.** Safety: When lifting points are used in a multileg assembly, care should be taken to calculate the WLL (Working Load Limit) due to the deration caused by forces acting in multiple directions. The reduction in WLL (Working Load Limit) for multileg assemblies should be checked with relevant Standards e.g. AS 3775-2004 Chain Slings-Gr t (8)

The lifting points should be mounted in such a way that they may easily be accessed for inspection and assembly/ disassembly of the sling.

- **7.** A plane bolting surface must be guaranteed to ensure correct mating of the lifting component.
- **8.** The VABH-B should be tightened to torque according to table 1 (+/- 10%).
- **9.** All fittings connected to the VABH-B should be free moving. When connecting and disconnecting the lifting means (wire ropes, chain slings, round slings) pinches and impacts should be avoided. Damage to lifting components caused by sharp corners should also be avoided.
- **10.** To prevent unintended dismounting through shock loading, rotation or vibration, thread locking fluid such as Loctite (depending on the application, please refer to the manufacturer's instruction) should be used to secure the bolt.
- **11.** If the lifting points are used exclusively for lashing, the value of the working load can be doubled. LC (lashing capacity) = $2 \times WLL$.
- **12.** Effects of temperature: Due to the DIN/EN bolts that are used with the VABH-B the working load limit should be reduced accordingly:

-10° to 100°C	no reduction	14°F to 212°F
100° to 200°C	minus 15%	212°F to 392°F
200° to 250°C	minus 20%	392°F to 482°F
250° to 350°C	minus 25%	482°F to 662°F

Temperatures above 350°C (662°F) are not permitted.

- **13.** RUD-Lifting points must not be used under chemical influences such as acids, alkaline solutions and vapours e.g. in pickling baths or hot dip galvanising plants. If this cannot be avoided, please contact the manufacturer indicating the concentration, period of penetration and temperature of use.
- **14.** After fitting, an annual inspection or sooner if conditions dictate should be undertaken by a competent person examining the continued suitability. Also inspect after damage and special occurrences.

Inspection criteria regarding paragraphs 2 and 14:

- Ensure correct bolt and nut size, quality and length.
- Ensure compatibility of bolt thread and tapped hole control of the torque
- · The lifting point should be complete.
- The working load limit and manufacturers stamp should be clearly visible.
- Deformation of the component parts such as body, load ring and bolt.
- Mechanical damage, such as notches, particularly in high stress areas.
- Wear should be no more than 10% (see wear indicators for measuring).
- · Evidence of corrosion.
- · Evidence of cracks.
- The excavator hook has to be mounted on plane bolting surfaces with the full back side.
- Opening of the mouth is deformed no more than 10%.
- Damage to the bolt, nut and/or thread.

Any non-adherence to this advice may result in damages of persons and/or materials!

EXCAVATOR HOOK - VABH-B



User Instructions - Part 3

Туре	Torque	Thread		
	Nm *	d		
VABH-B 1.5 t	55	M10		
VABH-B 2.5 t	100	M12		
VABH-B 4 t	240	M16		
VABH-B 6.5 t	450	M20		

Table 1

WORKING LOAD LIMITS (G - in tonnes)									
	Single Leg	2,	3 or 4 Le	egs					
PRODUCT DESCRIPTION	Ġ G		G						
		60° Maximum I	90° Included Angle	120° (Degrees)					
VABH-B 1.5 t	1.5	2.6	2.1	1.5					
VABH-B 2.5 t	2.5	4.3	3.5	2.5					
VABH-B 4 t	4.0	6.9	5.6	4.0					
VABH-B 6.5 t	6.5	11.2	9.2	6.5					

Picture 1

Table 2

Туре	WLL (t)	А	В	С	F	G	Н	I	L	MW	d	Weight (kg)	Reference	Package Unit
VABH-B 1.5t	1.5	7.5	78	117	70	48	60	38	15	25	M10	0.8	7991205	4
VABH-B 2.5t	2.5	8.5	101	148	85	60	75	49	18	30	M12	1.8	7991206	4
VABH-B 4t	4.0	11	122	171	104	70	90	59	25	35	M16	3.2	7991207	2
VABH-B 6.5t	6.5	13	156	208	120	85	110	70	30	40	M20	5.9	8502238	1

Table 3



